

Keep handy for changes between BST and GMT

Aspire

Changing the time on your Aspire

- Using a display key telephone
- Ensure that you do not have a call in progress
- Press **SPK** key (bottom right hand side of phone)
- Dial **828**
- Key in time in 24 hour format (e.g. 1545 = 3.45 pm)
- Press **SPK** key to hang up and complete

If you experience any difficulties resetting the time please contact DSM on:

T: 0844 8552271

E: service@dalys.co.uk

www.dalys.co.uk



maintaining business communications