

**Keep handy for changes between BST and GMT**

## Changing the time on a Nitusko/NEC DXE

- Press CL1 key (bottom right hand side of phone)
- Key in 828
- Key in password 0000
- Key in two digits for Year e.g. 09
- Key in two digits for Month e.g. 10
- Key in two digits for Day e.g. 26
- Key in one digit for the day of the week e.g. 1 for Monday (0-6 where 0=Sunday, 1=Monday, 2=Tuesday etc.)
- Key in two digits for the Hour (00-23)
- Key in two digits for the Minutes (00-59)
- Press SPK key to hang up and complete

**Example:** If you wanted to set the time/date to 9 o'clock on Monday 26 October 2009 the screen would show: 828 0000 09 10 26 1 0900

If you experience any difficulties resetting the time please contact DSM on:

**T: 0844 8552271**

**E: [service@dalys.co.uk](mailto:service@dalys.co.uk)**

**[www.dalys.co.uk](http://www.dalys.co.uk)**



**maintaining business communications**